



Continuous Ink System

Ideal for businesses, schools, and creative professionals who require consistent and high-quality print output



(CIS) technology revolutionized the printing industry by providing a more efficient and cost-effective solution for high-volume printing tasks



This not only reduces the need for frequent cartridge replacements but also significantly lowers the cost per page

CIS has gained popularity for its reliability and ease of maintenance

offering enhanced compatibility with various CANON models and further improvements in print quality and efficiency.



Affordable ink solutions. **Anydiel IT Services**

You have all the information on our website and our social networks.



Contact us

08986001630

<https://anydiel.my.canva.site>

FB: [Anydiel1982/](#)



Your CISS Instruction Manual

Presented by
Angel Caibigan Jr



How to Refill the Ink tank?

First, make sure you have the correct type of ink for your printer model. Begin by turning off your printer and unplugging it to ensure safety. Locate the ink tank compartment, which is usually located on the right side of the printer. Close the air tank cover and carefully open the ink tank cover and identify the ink reservoirs that need refilling. Next, gently remove the cap or seal from the ink bottle. Slowly pour the ink into the corresponding ink reservoir, being careful not to overfill it. Once filled, securely close the ink tank cap to prevent any leaks.

After refilling all necessary tanks, plug the printer back in. Turn it on and run a test print to ensure that the ink has been properly filled and that the printer is functioning correctly. If the print quality is not up to standard, you may need to run a cleaning cycle from the printer's maintenance menu.

Always dispose of empty ink bottles responsibly and wash your hands thoroughly after handling ink. Regularly checking and refilling your ink tanks can help maintain the longevity and performance of your printer.

How to bypass Ink Error in Canon Printer?



1

Canon printers are incapable of detecting the CISS ink tank level we have installed by default. It's normal to encounter a low ink level notification on your computer. Ignore it and continue printing. If there is an ink error that prevents the printer from printing.

2



Your printer will display a yellow light that blinks and a window message saying 'PRINTER RUN OUT OF INK' will appear. The error needs to be bypassed at that point.

3

Press and hold the stop button for approximately 10 seconds to solve the problem. This can only be done twice. One black cartridge and another one for the color cartridge. There were two events in total. After bypassing it, you won't get any low ink notifications on your computer anymore.



Ink Error Examples



Stop/Resume Button